



NUMERICAL SEQUENCE

INSTALLATION INSTRUCTIONS:

- Ensure main supply is switched off.
- Fit mounting bracket (1) onto mounting surface with self-tapping screws (2).
- Connect wires (3) according to color (White to White, Black to Black). Connect all earth lug together onto the crossbar with green screw to tight.
- Fit ceiling base (4) onto mounting bracket with nuts (5).
- Fit lamp (6) firmly into lampholder.
- Hang crystals (A, B) onto base according to the numerical sequence.
- Reconnect power.

WARNING:

- This fitting must be earthed.
- Disconnect power and allow fitting to cool down before cleaning or changing the lamp.